

**INSTALLATION AND OPERATION**  
OF YOUR  
**PEEK-A-BOOM**  
**MINI DEMO DISPLAY**

**INSTALLATION:**

Note: This cover is designed to be installed in place of the standard cover to turn your standard PB2 into a portable demo unit. Follow the instructions below. Remember to save the standard cover so that you can convert your demo unit back into a standard PB2.

1. Remove the cover from your PB2.
2. Unplug the multi-pin connector that connects the lower and upper boards. (take care here, the plug sometimes comes off hard, and damage can occur if you jerk too hard, Have patience)
3. Plug the multi-pin connector located on the mini demo unit into the upper board of the PB2. Take care that you plug it in correctly. The arrows should be up.
4. Now , using the screws from the standard cover, install the mini-demo cover on your PB2.

***YOUR MINI-DEMO UNIT IS NOW READY TO USE. JUST PUSH THE BUTTONS ON YOE KEY AND THE LIGHTS WILL LIGHT TO DEMONSTRATE THE BOOM OPERATION***

If your demo unit fails to operate, check the battery. It must be at least 8.5 volts to function.

**INSTALLATION AND OPERATION**  
OF YOUR  
**PEEK-A-BOOM**  
**MAXI DEMO DISPLAY**

**INSTALLATION:**

1. Remove the back cover from your maxi-demo box by turning the hold downs a quarter turn.
2. Pull the connection wires out through the slot provided and replace the cover.
3. Attach your PB2 to the front of the demo box using the hook and loop provided.
4. Connect the boom wires from your PB2 to the numbered wires on your demo unit. ( 1 to 1, 2 to 2, etc.)
5. Connect the alligator clips to the PB2 to power it. (red to red, black to black)
6. Plug the power supply into a 110 VAC outlet.

***YOUR MAXI-DEMO UNIT IS NOW READY TO USE. JUST PUSH THE BUTTONS ON YOE KEY AND THE LIGHTS WILL LIGHT TO DEMONSTRATE THE BOOM OPERATION***

**JOHNSON'S PEEK-A-BOOM**  
A PRODUCT OF  
**JOHNSON'S FARM,HOME & RECREATION, INC.**  
ITHACA, MICHIGAN  
PH - (517) 875-5117