



Quick Start Instructions for Assembling Trailered Units.

1. Remove all parts from the pallet.
2. Attach the wheel and tire assemblies to the axle. Bolt axle to the mounting brackets on the bottom of the trailer.
3. Install hitch assembly to the mounting point at the front of the trailer.
4. Gently heat the two drain hoses and connect them to their hose barbs on the bottom of the tank. Hot Water or a hair dryer are the best options. The hose length will determine which connector goes to each hose. Secure the hoses with the hose clamps provided.
5. Attach the Flow Meter assembly to the mounting point on the top rear of the tank. The output side of the meter (solenoid) should face to the left if you are standing behind the trailer.
6. Connect the short hose from the feed valve (farthest to the right from the back) to the inlet on the flow meter. Connect the feed dispensing hose and nozzle assembly to the outlet of the flow meter. Hook the feed dispensing hose to the hose saver.
7. Use the quick connect fittings on the front of the trailer to attach the U plug drain.



